

Web Site: www.parallax.com Technical: support@parallax.com Office: (916) 624-8333 Fax: (916) 624-8003 Sales: (888) 512-1024 Tech Support: (888) 997-8267

# DS1302 Real-Time Clock Module (#29125)

The DS1302 Real Time Clock Module provides a DS1302 real-time clock with a 32 kHz crystal and onboard battery backup, all in a small SIP module that can be easily plugged into a breadboard.

The DS1302 provides seconds, minutes, hours date, day of week and year with leap-year compensation up to the year 2100. You can use 24-hour mode or 12-hour mode with AM/PM indication and there are 31 bytes of RAM that are also battery-backed.

Give your project the ability to tell time, store time or make time-based decisions with 1 second resolution in a small, compact form-factor. Easily store settings or parameters using the 31 bytes of battery-backed RAM.

#### Features

- On-board CR1220 battery holder
- SPI interface supports 3-wire or 4-wire synchronous serial connection
- Wide operating voltage supports 3.3V and 5V microcontrollers
- Convenient SIP header makes breadboarding easy

#### **Specifications**


- Power Requirements: 3.3-5 VDC
- Current Requirements: 3.2 mA @ 5 VDC
- Communication Interface: SPI @ Vdd (3 or 4 wire)
- Operating temperature: +32 to +158 °F (0 to +70 °C)
- Dimensions: 1.22 x 0.6 in (31.2 x 15.5 mm)


## **Application Ideas**

- **Electronic Clock**
- Datalogger with Date/Time stamp
- Sprinkler Control Timer



## **Quick-Start Circuit**





The above connection diagram is typical for a BASIC Stamp 2 or Propeller Microcontroller, however if you are trying to connect to a microcontroller that uses a 4-wire SPI interface then you should follow the connection diagram below.




Figure 2: Connecting to a microcontroller with a 4-wire SPI interface

#### **Resources and Downloads**

Check for the latest version of this document, free software, and example programs from the DS1302 RTC Module product page. Go to www.parallax.com and search 29125.

#### **Precautions**

• Because this module contains a lithium coin-cell battery for backup it is important not to enable the DS1302 trickle-charging circuit. This could damage the battery and/or module.

Pin	Name	Туре	Function
1	VCC	Р	Supply Voltage (3.3-5 VDC)
2	GND	G	Ground
3	I/O	I/O	Data Input / Output
4	N/C	—	No Connection
5	SCLK	I	Serial Clock
6	CE	I	Chip Enable

# Pin Definitions (3-Wire Interface)

Pin Type: P = Power, G = Ground, I = Input, O = Output



## **Pin Definitions (4-Wire Interface)**

Pin	Name	Туре	Function
1	VCC	Р	Supply Voltage (3.3-5 VDC)
2	GND	G	Ground
3	MISO	0	Master In, Slave Out
4	MOSI	I	Master Out, Slave In
5	SCK	I	Serial Clock
6	CS	I	Chip Select

Pin Type: P = Power, G = Ground, I = Input, O = Output



#### **Module Dimensions**

